

IchigoJam first step

Light up the LED

```
LED1
```

Type "LED1" and hit enter

Light off the LED

```
LED0
```

Every line needs to hit enter

Order your computer to wait for a while

```
WAIT120
```

"WAIT120" means "wait 2sec" Q:"WAIT60" means?

```
WAIT60
```

Light up the LED 1sec (`:` to join commands)

```
LED1:WAIT60:LED0
```

Hit the UP key twice.

Hit the RIGHT key 12 times.

Hit the Backspace key to delete "6".

Type "12". Hit Enter to modify your order.

```
LED1:WAIT120:LED0
```

Blink the LED

(Hit the Space key to input space)

```
10 LED1:WAIT30
20 LED0:WAIT30
30 GOTO10
RUN
```

"RUN" is a command to start your program.

Hit the **ESC** key to stop the program.

Also the F5 key is same as "RUN".

"LIST" is a command to display the program.

```
LIST
```

F4 key works the same way

Can you blink the LED more fast?

Enter key to tell computer your modification

You can save up to four programs (0 to 3)

```
SAVE0
```

The F3 key types "SAVE"

After reboot your computer,

you can load that program.

```
LOAD0
```

The F2 key types "LOAD"

Type "NEW" to clear your program.

```
NEW
```

